

## Cylinder block, crankshaft and flywheel, disassembly and assembly

### Note:


Replace all gaskets and seals.

#### 1 - Thrust washers

- ◆ Measuring axial clearance of crankshaft ⇒ [Page 13-21](#)
- ◆ Thrust washer only fitted on 4th crankshaft bearing

#### 2 - Special bolt (double hex)

- ◆ Replace
- ◆ Dual-mass flywheel: 60 Nm + 180° (1/2 turn)



### 3 - Dual-mass flywheel

- ◆ Removing and installing ⇒ [Page 13-29](#)
- ◆ Removing and installing needle bearing ⇒ [Page 13-35](#)

### 4 - Crankshaft bearing

- ◆ Checking axial and radial clearance ⇒ [Page 13-21](#)

### 5 - Bolt, tightening torque 10 Nm


### 6 - Oil spray jet

- ◆ For piston cooling

### 7 - Oil seal for rear sealing flange

- ◆ Replacing ⇒ [Page 13-23](#)

13-16



**8 - Bolt, tightening torque 10 Nm**

**9 - Rear sealing flange**


**10 - Gasket**

**11 - Bolt, tightening torque 25 Nm**

- ◆ Screw in bolts on left and right sides finger-tight before tightening bolts on main bearing caps.

**12 - Cylinder block**

**13 - Gasket**



**14 - Collar bolt, tightening torque 30 Nm**

- ◆ Apply Loctite™ when installing

**15 - Bolt, tightening torque 10 Nm**

**16 - Front sealing flange**

**17 - Expansion pins**

**18 - Crankshaft**


- ◆ Checking ⇒ [Page 13-21](#)

**19 - Chain sprocket for oil pump**

- ◆ Removing and installing ⇒ [Page 17-62](#) .

**20 - Pistons**

- ◆ Checking ⇒ [Page 13-36](#)



### 21 - Piston rings

- ◆ Checking ⇒ [Page 13-36](#)

### 22 - Circlip for piston pin


### 23 - Piston pin

### 24 - Connecting rod

- ◆ Mark cylinder number and installation position of matching connecting rods and bearing caps before removing
- ◆ Installation position: wider, slightly convex machined surfaces on the same side

### 25 - Connecting rod bearing

- ◆ Do not interchange used bearing shells.
- ◆ Connecting rods, connecting rod bearings ⇒ [Page 13-39](#)



### 26 - Connecting rod bearing bolts

- ◆ Always replace
- ◆ Tightening torque: 30 Nm + 90° ( $\frac{1}{4}$ turn)
- ◆ When measuring radial clearance, tighten to 20 Nm but do not turn further.

### 27 - Main bearing cap


- ◆ Marking -1- on oil pump side
- ◆ Replace bolts for main bearing caps
- ◆ Watch position of dowel sleeves
- ◆ Checking bearing clearance ⇒ [Page 13-21](#)

### 28 - Bolts for main bearing caps

- ◆ Always replace
- ◆ Tightening torque ⇒ [Page 13-20](#)
- ◆ Tightening sequence ⇒ [Page 13-20](#)

## Crankshaft bearing caps, installing

- Bearing -1- is at the toothed belt end; bearing -4- is at the flywheel end.



### ⚠ Tightening sequence:


- Stage 1 Tighten all bolts in the sequence shown (1 - 16) to 30 Nm.
- Stage 2 Tighten all bolts in the sequence shown (1 - 16) to 60 Nm.
- Stage 3 Using a fixed wrench, turn all bolts in the sequence shown (1 - 16) 90° further.
- Tighten bolts -A- to 25 Nm.

## Crankshaft axial and radial clearance, measuring

### Axial clearance

#### Note:

*Do not interchange used bearings.*



A

- Attach dial gauge with universal dial gauge bracket VW 387 to oil pump and bring it into contact with crank web.
- Press crankshaft against dial gauge by hand and set gauge to -0-.
- Press crankshaft away from dial gauge.
- Note reading:

Clearance when new	Wear limit
0.090 ... 0.251 mm	0.28 mm



**Radial clearance**

Measure radial clearance with Plastigage™.


- Read value:

<b>Clearance when new</b>	<b>Wear limit</b>
0.018 ... 0.045 mm	0.10 mm

## Crankshaft oil seals, replacing

### A - Toothed belt end

- Remove toothed belt ⇒ [Page 13-4](#) .
- Remove toothed belt sprocket from crankshaft




- A** - Pull out oil seal with oil seal extractor 3203.
- Clean contact surface and sealing surface.

### **Note:**

*Do not lubricate sealing lip or outer circumference of seal before pressing in.*

- Push on seal using fitting sleeve 3202/1.



- A** - Press in seal until flush using fitting sleeve 3265 and central bolt.

**B - Flywheel end****Note:**


*Replace oil seal together with sealing flange.*

**Vehicles with manual transmission**

- Drain off coolant ⇒ [Page 19-19](#) .
- Remove transmission.

⇒ [Repair Manual, 6 Spd. Manual Transmission 01E, Repair Group 34](#)

- Remove clutch.
- With crankshaft at TDC, screw in clamping bolt 3242.
- Mark position of flywheel relative to engine -arrows-.
- Remove dual-mass flywheel.
- Remove sealing flange.

**A**

## Installing

- Install sealing flange.
- Install dual-mass flywheel with new bolts.

### **Note:**

*Always replace securing bolts for dual-mass flywheel.*

- Install clutch.

⇒ [Repair Manual, 6 Spd. Manual Transmission 01E, Repair Group 30](#)


<b>Tightening torques</b>	
Dual-mass flywheel to crankshaft	60 Nm + 180°
Clutch to dual-mass flywheel	20 Nm

### Vehicles with automatic transmission

- Remove transmission.

⇒ [Repair Manual, 5 Spd. Automatic Transmission 01V, Repair Group 37](#)

- Drain off coolant ⇒ [Page 19-19](#) .



A

- Turn crankshaft to TDC by hand. Marks -A- and -B- must be aligned.

#### **Note:**


*Turn over the engine at the central bolt on the crankshaft.*

- Check position of camshafts: larger holes in securing plates on camshaft sprockets must align opposite one another on inside. If this is not the case, turn crankshaft one revolution further.
- Remove sealing plug from cylinder block, left.
- The TDC drilling in crankshaft must be visible (or able to be felt) in line with sealing plug hole.

#### **CAUTION!**


***Injury risk - do not turn engine while feeling for TDC drilling.***

13-27



- A**
- Screw clamping bolt 3242 for crankshaft into sealing plug hole and tighten.
  - Mark positions of holes in drive plate, shim -1- and washer -2- in relation to crankshaft.
  - Mark positions of shim -1- in front of drive plate and washer -2- behind drive plate.

### Installing



- A**
- Install drive plate with washer -2- and shim -1- (3.0 mm or 4.0 mm).


### Note:

- ◆ *Short engines and exchange engines are supplied without bush in crankshaft. On vehicles with automatic transmission, always knock in new bush before installing drive plate.*
- ◆ *Always replace drive plate securing bolts.*

Tightening torques	
Drive plate to crankshaft	60 Nm + 90°

**Note:**

*Always replace securing bolts for drive plate.*



A

- Measure distance -a- at three points and calculate average value.
  - ◆ Distance -a- = approx. 29.9 mm.
- Install a different shim if necessary.

**Note:**

*Before installing the transmission, check that the dowel sleeves for locating engine/transmission are fitted in the engine flange.*

- Install transmission.

⇒ [Repair Manual, 5 Spd. Automatic Transmission 01V, Repair Group 37](#)

## Dual-mass flywheel / drive plate, installation dimensions, removing and installing


### A - Flywheel

#### Removing

- Remove transmission.

⇒ Repair Manual, 6 Spd. Manual Transmission  
01V, Repair Group 34

- Remove clutch.



A

- With crankshaft at TDC, screw in clamping bolt 3242.
- Mark position of flywheel relative to engine -arrows-.
- Remove bolts (bolts must be replaced).



**Note:**

*The needle bearing is located in the flywheel and must be pressed in if a new flywheel is installed  
⇒ [Page 13-35](#) .*

**Installing**

- Install dual-mass flywheel.

**Note:**

*Always replace flywheel securing bolts.*

- Install clutch.

⇒ [Repair Manual, 6 Spd. Manual Transmission 01E, Repair Group 30](#)

- Install transmission.

⇒ [Repair Manual, 6 Spd. Manual Transmission 01E, Repair Group 34](#)


<b>Tightening torques</b>	
Dual-mass flywheel to crankshaft	60 Nm + 180 <sup>o</sup>
Clutch to dual-mass flywheel	20 Nm

### **B - Drive plate**

#### **Removing**

- Remove transmission.

⇒ [Repair Manual, 5 Spd. Automatic Transmission 01V, Repair Group 37](#)



**A**

- Turn crankshaft to TDC by hand. Marks -A- and -B- must be aligned.

#### **Note:**


*Turn over the engine at the central bolt on the crankshaft.*

- Check position of camshafts: larger holes in securing plates on camshaft sprockets must align opposite one another on inside. If this is not the case, turn crankshaft one revolution further.
- Remove sealing plug from cylinder block, left.

- TDC drilling in crankshaft must be visible (or able to be felt) in line with sealing plug hole.


**CAUTION!**

***Injury risk - do not turn engine while feeling for TDC drilling.***



**A**

- Screw clamping bolt 3242 for crankshaft into sealing plug hole and tighten.
- Mark positions of holes in drive plate, shim -1- and washer -2- in relation to crankshaft.
- Mark positions of shim -1- in front of drive plate and washer -2- behind drive plate.



## Installing


A

- Install drive plate with washer -2- and shim -1- (3.0 mm or 4.0 mm).

### Note:

- ◆ *Short engines and exchange engines are supplied without bush in crankshaft. On vehicles with automatic transmission, always knock in new bush before installing drive plate.*
- ◆ *Always replace drive plate securing bolts.*

Tightening torques	
Drive plate to crankshaft	60 Nm + 90°



- A**
- Measure distance -a- at three points and calculate average value.
    - ◆ Distance -a- = approx. 12.3 mm.
  - Install a different shim if necessary.


**Note:**

*Before installing the transmission, check that the dowel sleeves for locating engine/transmission are fitted in the engine flange.*

- Install transmission.

⇒ [Repair Manual, 5 Spd. Automatic Transmission 01V, Repair Group 37](#)

### Needle bearing in dual-mass flywheel, removing and installing

**A**

- Pull out with puller, such as KUKKO 21/2 and KUKKO 22-1.
- Drive in with drift 3264.

## Pistons and piston rings, installing

### Pistons



- A** Position: arrow on piston crown must always face in direction of travel.
- Mark cylinder number on piston crown with waterproof felt pen.


### Note:

*Do not use a center-punch or similar, as pistons have a special coating.*

### Checking piston diameter


- A**
- Measure pistons approx. 10 mm from bottom of skirt, at 90° to piston pin axis.
    - ◆ Difference between actual and nominal diameter: not more than 0.04 mm.





### A Ring-to-groove clearance

Clearance when new	Wear limit
0.02 ... 0.08 mm	0.10 mm




### A Checking piston ring gap

- Push ring in squarely to a position approx. 15 mm from bottom end of cylinder.

Piston ring	Gap when new	Wear limit
1	0.35 ... 0.50 mm	1.0 mm
2	0.50 ... 0.70 mm	1.4 mm
3	0.25 ... 0.50 mm	0.8 mm





### Cylinder bores, checking

A

- Measure bores at three points in both directions: across engine -A- and in line with crankshaft -B-.

Use internal dial gauge 50 to 100 mm.

- ◆ Difference between actual and nominal diameter: not more than 0.08 mm.

### Piston and cylinder dimensions

Honing dimension	Piston dia.	Cyl. bore dia.
Basic dimension	80.95 mm	81.01 mm


#### Note:

*Replacement pistons are only available with basic dimension.*

## Connecting rods and connecting rod bearings, installing

### Note:

- ◆ Only replace complete sets of connecting rods
- ◆ Do not interchange connecting rod bearings.



A

- Before removing, mark positions of connecting rod bearing caps with a felt pen or similar.

### Checking radial clearance

- Remove connecting rod bearing cap. Clean bearing cap and bearing journal.
- Place a length of Plastigage corresponding to width of bearing on bearing journal or bearing shell.
- Install connecting rod bearing cap and tighten to 20 Nm. Do not rotate crankshaft.
- Remove connecting rod bearing cap again.
- Compare width of Plastigage with calibrated scale.

Clearance when new	Wear limit
0.015 ... 0.062 mm	0.12 mm

- Install new connecting rod bearing bolts.