




Active loudspeakers, rear

- J402 - Operating electronics control unit, navigation 
- R12 - Amplifier
- R15 - Bass loudspeaker, rear left
- R17 - Bass loudspeaker, rear right
- R34 - Mid-range/treble loudspeaker, rear left
- R35 - Mid-range/treble loudspeaker, rear right
- R100 - Bass loudspeaker
- T20b - 20-pin connector, black, door, B pillar, left
- T20c - 20-pin connector, black, door, B pillar, right
- T20d - 20-pin connector, black, radio connector I
- 346 - Earth connection (audio), in dash panel wiring harness



* - Only applies to models with active loudspeakers



97-56651